



857611

A	⊘ Not for sale	Kit Mounting Cab Assembly	1
1	335/11631	Mount Cab 30mm CTS	1
2	335/11632	Mount Cab 38mm CTS	1
3	331/60589	Mounting Flexible	4
4	823/10121	Washer rebound	4
5	1315/3718D	Bolt M16 x 80mm < Supersession	3
6	1315/3715Z	Bolt M16x65	1
7	1420/0008D	Washer M10 < Supersession	2
8	1370/0303D	Nut Lock M10 < Supersession	2
9	1315/0408D	Setscrew M10 x 30 G8.8 < Supersession	2
10	1315/0401D	Screw M10 x 12 < Supersession	1
11	926/49800	Seal Cab Sealing Strip	1
12	331/22334	Panel soundproofing	1
13	333/S5060	Strip Sealing	1