




1400 > D1-1-6 CONTROLS LOADER VALVE



095510

1	1305/0105Z	Bolt < 更替	1
2	109/50206	Joint Ball	1
3	826/00612	Joint Ball	2
4	1305/0103Z	Screw < 更替	1
5	1416/0005	Washer < 更替	2
6	1417/0014Z	Washer Locking (1/2") 更替 >	2
7	122/67448	Rod 188 long	1
8	122/67447	Rod 208 long	1
9	1340/0102Z	Nut < 更替	2
10	1340/0101Z	Nut < 更替	2
11	913/00900	Clevis right hand thread	2
12E	:123/00719	Cover loader controls	1
12G	:123/01223	Plate gaiter retainer	1
12F	⊗ 非卖品	Gaiter 更替 >	1
12A	:123/01272	Console loader controls	1
12D	:826/00942	Screw > 不再提供	2
12B	:826/00943	Holder	2
12C	:826/00944	Retainer	2
12H	:828/00239	Plug 95mm OD 69MM ID x 76mm Use with 2 spool loader valve only.	1
12	⊗ 非卖品	Multi Supersession Part MSS use items 12A, 12B, 12C, 12D & 12E	1

13	122/67450	Gaiter	1
14	826/00687	Screw <M325312 < 更替	4
14	826/00887	Retainer Scrivet	4
15	⊘ 非卖品	Plate	1
16	122/82600	Lever	1
17	1412/0001Z	Washer 1/4" Large 更替 >	1
18	828/00160	Plug 85mm OD 60mm ID x 66mm Remove when fitting Aux. lever item 34.	1
19	826/00847	Fastener Drive Dark Grey < 更替	4
19A	993/78400	Knob Assembly 更替 >	1
20	:122/67456	Knob top 更替 > Part NLA use item 19A	1
21	⊘ 非卖品	Knob base 更替 > Part NLA use item 19A	1
22	122/67459	Ring tolerance 更替 > 122/67459A 在替代鏈中找到	1
23	⊘ 非卖品	Button dump 更替 > Part NLA use item 19A	1
24	701/14700	Switch micro > 不再提供	1
25	826/00866	Screw	6
26	706/63500	Harness <M Deleted, now part of 706/69200 > 不再提供	1
27	120/61005	Pin pivot Welded to Bracket	1
28	2203/0022	Circlip	1

29	913/00900	Clevis right hand thread	2
30	122/67449	Rod	1
31	1340/0102Z	Nut < 更替	2
32	122/35511	Gaiter < 更替	1
33	122/38503	Knob yellow Items 27-41 & 47-50 are for Aux Valve control > 不再提供	1
34	122/82100	Lever Control > 不再提供	1
35	121/15500	Bracket	1
36	831/00063	Bearing self lubricating	2
37	2102/0411	Pin tension	1
38	811/50059	Pin pivot	1
39	828/00161	Grommet Red	1
40	122/38301	Plate gaiter retainer	1
41	1430/0202	Screw No 8x1/2"	3
47	826/00612	Joint Ball	2
48	122/67446	Rod	1
49	1410/0002Z	Washer (5/16" Small) < 更替	2
50	1340/0101Z	Nut < 更替	2