




A	⊘ Not for sale	None serviced part < Supersession See A1-2-3	1
1	⊘ Not for sale	Clam assembly and backblade	1
2	::531/15500	Blade back Was 511/15500	1
3	:::108/59204	Plate toe < Supersession	1
4	::1305/3222Z	Bolt 3/8 < Supersession	6
5	::1340/0203Z	Lock Nut 3/8" UNF < Supersession	11
6	::1021/3821	Pin pivot	2
7	::1450/0001	Nipple Grease, Straight 1/8 BSP < Supersession	2
8	::1305/3236	Bolt	2
9	::811/80013	Pin pivot	2
10	::1019/3832	Pin pivot	2
11	::1017/2032	Pin pivot > No Longer Available	2
12	::531/15600	Clam	1
13	:::531/15605	Plate reinforcing	1
13	:::531/15606	Plate toe one piece	1
14	:1017/2006	Pin pivot	2
15	:1305/3226	Bolt L=1.3/4" < Supersession	2
16	:1209/0026	Bush	2
17	:531/03205	Tooth Supersession >	6
18	::826/00303	Bolt Plough 3/4" UNF x 70mm	12

18	::1340/0701Z	Nut 3/4 < Supersession	18
18	⊘ Not for sale	Multi Supersession	1
19	⊘ Not for sale	'See Remark' Clam Ram. See Index E.	2
20	:612/20700	Hose 3/8"BSP x 345mm	4
21	:120/84900	Pipe	2
21	:121/26900	Pipe	2
22	:120/84700	Pipe Part N/A. Use 121/26700 + 121/26900	1
22	:121/26700	Pipe	1
23	:120/84800	Pipe Part N/A. Use 121/26800 + 121/26900	1
23	:121/26800	Pipe	1
24	:821/00055	Clamp Pipe top Supersession >	1
25	:817/00151	Label	1
26	990/69701	Plate toe Optional bolt on type.	1
27	826/00217	Ploughbolt 3/4UNF x 2-1/4" < Supersession	6
28	1416/0011	Washer	6
29	1340/0701	Nut Supersession >	6
30	1340/0701	Strin reinforcing	.