




1400 > E2-2-4 PUMP, MAIN HYDRAULIC STANDARD



1	:816/10039	Adapter bulkhead Supersession >	1
1	⊘ Not for sale	Pump main hydraulic Supersession >	1
1	:1406/0019	Washer Bonded	1
1	:1406/0021	Washer Bonded < Supersession	1
1	:1604/0006	Adaptor G3/4A-G3/4A Supersession >	1
1	:1606/0011	Adapter	1
1	:1606/0017	Adapter 5/8" x 1/2" M/M < Supersession	1
1	⊘ Not for sale	Multi Supersession	1
2	⊘ Not for sale	Gear set > No Longer Available	1
3	:920/01684	Gear set < Supersession	1
4	:920/01646	Kit-repair Use with 919/64600,919/67000 & 919/71600 > No Longer Available	1
4A	::920/01804	Plate wear < Supersession Use with 919/71600	4
5	::920/01647	Kit-seal < Supersession Use with 919/64600 & 919/67000	1
5	::920/01845	Kit-seal pump Use with 919/71600	1
6	⊘ Not for sale	None serviced part	1
7	⊘ Not for sale	Dowel < Supersession	4
8	⊘ Not for sale	None serviced part	1
9	:920/00160	Screw grub > No Longer Available	1

10	⊘ Not for sale	None serviced part	1
11	:920/01675	Kit-bolt > No Longer Available	4
12	:920/00967	Washer	4
13	⊘ Not for sale	Coupling splined > No Longer Available	1
14	:920/00771	Key	1
15	:920/00772	Circlip	1
16	833/00048	Adapter suction	1
17	2401/0218	O Ring < Supersession	1
18	1305/1908Z	Bolt 1/2" UNC x 1 1/4" < Supersession	4
19	1416/0008Z	Washer Spring (1/2") < Supersession	4
20	1606/0009	Adapter Reducing M/M < Supersession	1
21	1406/0018	Washer Bonded (1/2" BSP) < Supersession	1
22	1605/0022	Adapter < Supersession Road breaker system only	1
22	1605/0022	Adapter <M 359072 < Supersession	1
22	1606/0017	Adapter 5/8" x 1/2" M/M < Supersession	1
23	1406/0018	Washer Bonded (1/2" BSP) < Supersession	1
24	1340/0403Z	Nut Lock 1/2inUNF < Supersession	2
25	1305/0412Z	Bolt 1/2" x 1.3/4" long < Supersession Bolt dump to mainframe	2