




A	⊘ Not for sale	Assembly FUEL SYSTEM	1
1	401/Y4165	ABI Fuel Sender < Supersession	1
2	332/V0994	Plate	1
3	335/D8469	Plate Clamping Fuel sender	1
4	1420/0006D	Washer Plain M6 < Supersession	4
5	1315/0205D	Setscrew M6 x 20 G8.8 < Supersession	4
6	403/D8962	Cap Diesel Filler Vented Supersession >	1
7	335/E1431	Mount Filter Secondary WA	1
8	1420/0007D	Washer M8 < Supersession	8
9	1315/0307D	Setscrew M8 x 25mm G8.8 Supersession >	6
10	320/A7170	Element -A-1B-07MB-179-08 < Supersession 320/07394 found in supersession chain	1
11	335/E1449	Pressing Fuel Filter Clamp	1
12	335/E0863	Plate Primary Filter Mount	1
13	1370/0203D	Nut Lock M8 < Supersession	2
14	320/A7086	Filter fuel (30 micron) < Supersession	1
15	1420/0008D	Washer M10 < Supersession	4
16	1315/0410D	Setscrew M10 x 40mm < Supersession	2
17	1370/0303D	Nut Lock M10 < Supersession	2
18	335/D9990	Hose Sender to Primary Filter	1

19	335/E1548	Hose Primary Filter to Pump	1
20	335/E1566	Hose Pump to Section Filter	1
21	828/00237	O Ring 1/4"BSP < Supersession	2
22	335/F1656	Hose Fuel Filter to Engine < Supersession	1
23	335/G2106	Hose Fuel Rail to Tank(Return)	1
24	2201/0001	Clip Worm Drive 8/16mm < Supersession	3
25	332/X8091	P-Clip 18 mm	1
26	123/05247	Clip Cable	1
27	2410/0205	Grommet Hole Diameter 12.7mm	1
28	826/01144	Cable Tie 200mm	2