




L310-1-2 INDUCTION FILTER COMPONENTS



580-12127-1

A	580/12127	Filter Assembly	1
1	580/12127	Filter Assembly	1
2	:32/925315	Cover assembly	1
3	:32/915704	Valve Dust Valve < Supersession	1
4	:32/917301	Element air filter main < Supersession	1
5	:32/917302	Element air filter safety < Supersession	1
6	:32/917400	Bracket Air Cleaner Mounting	1
7	816/40057	Adaptor elbow 90	1
8	701/58721	Switch Vacuum Pressure Supersession >	1
9	1315/0308Z	Setscrew M8 x 30	2
10	1420/0007Z	Washer (M8) Supersession >	2