




802 > C1-2-1 PANEL, INSTRUMENT



069370

|    |           |                                                |   |
|----|-----------|------------------------------------------------|---|
| 1  | 211/00401 | Panel<br>> No Longer Available                 | 0 |
| 2  | 704/00800 | Meter hour<br>Supersession >                   | 0 |
| 3  | 716/00500 | Box fuse                                       | 0 |
| 4  | 703/07802 | Fuse 8 amp<br>< Supersession                   | 0 |
| 5  | 106/09103 | Bracket<br>> No Longer Available               | 0 |
| 6  | 826/00031 | Nut 'U'                                        | 0 |
| 7  | 1430/0305 | Screw self tapping<br>< Supersession           | 0 |
| 8  | 826/00021 | Nut 'U'                                        | 0 |
| 9  | 826/00023 | Screw spire                                    | 0 |
| 10 | 700/12000 | Housing warning light<br>> No Longer Available | 0 |
| 11 | 826/00605 | Screw M4x25                                    | 0 |
| 12 | 720/10049 | Bulb capless<br>< Supersession                 | 0 |
| 14 | 716/01600 | Diode                                          | 0 |
| 15 | 204/07006 | Tie Cable 115mm                                | 0 |
| 16 | 701/04300 | Switch heater<br>> No Longer Available         | 0 |
| 17 | 701/05600 | Switch Wash/wipe                               | 0 |
| 18 | 701/04400 | Switch working light<br>< Supersession         | 0 |
| 19 | 701/01201 | Bulb<br>< Supersession                         | 0 |
| 20 | 701/01202 | Holder Bulb                                    | 0 |
| 21 | 701/02600 | Switch ignition<br>Supersession >              | 0 |

|    |           |                                             |   |
|----|-----------|---------------------------------------------|---|
| 22 | 988/00177 | Key<br>< Supersession                       | 0 |
| 23 | 826/00270 | Nut                                         | 0 |
| 24 | 256/05708 | Cap Splash<br>> No Longer Available         | 0 |
| 25 | 815/00050 | Plate switch<br>> No Longer Available       | 0 |
| 26 | 716/00102 | Resistor<br>> No Longer Available           | 0 |
| 27 | 826/00274 | Clip                                        | 0 |
| 28 | 1430/0105 | Screw<br>< Supersession                     | 0 |
| 29 | 704/00700 | Alarm 12volt                                | 0 |
| 30 | 826/00003 | Screw                                       | 0 |
| 31 | 1416/0003 | Washer<br>< Supersession                    | 0 |
| 32 | 1358/0201 | Nut<br>Supersession >                       | 0 |
| 33 | 703/07200 | Switch Test button<br>> No Longer Available | 0 |
| 34 | 256/05709 | Cover Rubber                                | 0 |