




1A	714/01600R	Alternator service ex. BLMC 4.98 Engines > No Longer Available	1
1A	⊘ Not for sale	Alternator service ex. 4.236 Engines > No Longer Available	1
1A	714/06800R	Alternator 4.236 Engines > No Longer Available	1
1	714/11300	Label Adhesive REFER TO PAGE C2-4-3 FOR SERVICE PARTS	1
1	714/11400	Alternator 45Amp REFER TO PAGE C2-4-4 FOR SERVICE PARTS	1
1	⊘ Not for sale	Multi Supersession	1
1	⊘ Not for sale	Multi Supersession	1
2	⊘ Not for sale	Cover	1
3	:714/00601	Regulator < Supersession	1
4	:714/00605	Rectifier < Supersession	1
4A	::714/03205	Diode Surge protection Not illustrated part of Rectifier	1
5	⊘ Not for sale	Bracket Drive end BLMC 498 Engine	1
5	⊘ Not for sale	Bracket Drive end Supersession > 4.236 Engine	1
6	:714/00606	Kit-bearing Drive end < Supersession BLMC 498 Engine	1
6	⊘ Not for sale	Kit-bearing drive end 4.236 Engine	1
7	⊘ Not for sale	Rotor assembly < Supersession	1
8	⊘ Not for sale	Ring slip < Supersession	1

9	⊘ Not for sale	Kit-bearing Slip ring end < Supersession	1
10	⊘ Not for sale	None serviced part < Supersession Slip Ring End Bracket	1
11	⊘ Not for sale	Stator < Supersession	1
12	⊘ Not for sale	Box Brush < Supersession	1
13	⊘ Not for sale	Kit-brush Supersession >	1
14	⊘ Not for sale	Bolt Through	3
15	⊘ Not for sale	Kit-sundry parts Kit < Supersession	1
16	714/00701	Fan < Supersession BLMC 498 Engine	1
16	⊘ Not for sale	Fan 4.236 Engine	1
17	⊘ Not for sale	Pulley 4.236 Engine	1
17	⊘ Not for sale	Pulley < Supersession BLMC 498 Engine	1