




B1-3-1 CENTRE PIVOT



A	⊘ Not for sale	Pivot centre assembly	1
1	911/40112	Pin pivot Supersession >	1
3	331/43951	Plate thrust	1
4	331/53558	Joint centre	1
5	1391/3515D	Capscrew M12 x 65 < Supersession	4
6	831/10398	Bearing oscillation < Supersession	2
7	831/10211	Bearing liner, 70x84x57 slew pivot Supersession >	2
8	332/R9352	Cover rear centre joint	1
9	823/10618	Shim	1
10	823/10619	Shim	2
11	813/00456	Seal grease, pivot pin	4
12	904/20326	Seal	2
13	1450/0001	Nipple Grease Straight 1/8" < Supersession	2
14	1315/0710D	Setscrew M16 x 40mm < Supersession	1
15	1420/0007D	Washer M8 < Supersession	2
16	821/10395	Clamp hose,(4 hose)	2
17	821/10396	Clamp hose,(3 hose)	1
18	331/49800	Plate top,hose clamp	1
19	1370/0203D	Nut Lock M8 < Supersession	2
20	823/10722	Washer thrust	2

21	830/00599	Spacer Keep Plate	1
22	1412/0007D	Washer (5/8" Large)	1
23	332/R9385	Spacer centre joint	4
24	1391/3511D	Capscrew M12 x 45mm G12.9 < Supersession	2
25	1422/0009D	Washer Hardened M12	2
26	332/R9423	Plate mount WA	1