




1400 > H1-1-1 STEERING COLUMN



1	⊘ Not for sale	Wheel steering Supersession >	1
2	116/00408	Cover	1
3	123/00492	Cap	1
4	1340/0103Z	Nut 5/16" UNF < Supersession	1
5	123/00491	Knob	1
6	1420/0007Z	Washer (M8) Supersession >	1
7	150/32303	Spindle	1
8	1410/0003Z	Washer (3/8" Small) < Supersession	1
9	1340/0602Z	Nut Supersession >	1
10	1411/0007Z	Washer 5/8 Supersession >	1
11	G18/2	Key < Supersession	1
12	123/01390	Shaft steering column < Supersession	1
13	831/00074	Washer Grooved	1
14	826/00793	Pin tension Supersession >	2
15	192/16400	Column Steering Supersession >	1
16	:917/02000	Bearing	2
17	1410/0009Z	Washer < Supersession	1
18	1420/0012Z	Washer M20 < Supersession	1
19	1305/0206Z	Setscrew (3/8" UNF x1") < Supersession	2

20	1340/0203Z	Lock Nut 3/8" UNF < Supersession	2
21	:45/905400	Coupling Supersession > 331/36009 found in supersession chain	1
21	45/905400	Coupling Supersession > 331/36009 found in supersession chain	1
21	:821/00190	Clip 'E' < Supersession	1
21	⊘ Not for sale	Multi Supersession <M	1
22	826/00653	Bolt	1
23	823/00232	Washer	1
24	1340/0103Z	Nut 5/16" UNF < Supersession	1
25	255/35203	Mount Resilient < Supersession	4
26	⊘ Not for sale	'See Remark' Steering unit see frame E3-10-1	1
27	1315/0409Z	Setscrew M10 x 35mm < Supersession	4
28	123/00161	Plate Retainer	1
29	823/00408	Washer 2mm	4
30	821/00173	Clip E <M Use with 45/901000 item 21	1
30	821/00190	Clip 'E' < Supersession Use with 45/905400 item 21	1
31	823/00326	Washer M10 X 30mm	1