



1	714/40294	Motor starter Supersession >	1
2	714/36100	Alternator assembly Supersession >	1
3	701/54400	Switch temperature sender M16	1
4	716/30129	Sensor Temperature M16 <i>Hyd Oil Sensor</i>	1
5	716/30071	Sensor low water level	1
6	701/54500	Switch oil pressure Supersession >	1
7	JNH0070	Adaptor Vacuum Sensor	1
8	717/20223	Thermostart > No Longer Available	4
9	717/20170	Lead connector, glow plug	1
10	716/26800	Relay thermostart < Supersession	1
11	701/57400	Sensor engine speed	1
12	716/30091	Solenoid Engine stop Supersession > 332/J5060 found in supersession chain	1
13	716/30180	Relay potentiometer Supersession >	1
14	928/60027	Valve Solenoid Proportional	1
15	KRH5038	Cap terminal < Supersession	1