




1400 > H1-1-1 STEERING COLUMN



|    |            |                                                                                  |   |
|----|------------|----------------------------------------------------------------------------------|---|
| 1  | 116/00522  | Wheel steering<br>Supersession ><br><b>333/Y5768</b> found in supersession chain | 1 |
| 2  | 116/00408  | Cover                                                                            | 1 |
| 3  | 123/00492  | Cap                                                                              | 1 |
| 4  | 1340/0103Z | Nut 5/16" UNF<br>< Supersession                                                  | 1 |
| 5  | 123/00491  | Knob                                                                             | 1 |
| 6  | 1420/0007Z | Washer (M8)<br>Supersession >                                                    | 1 |
| 7  | 150/32303  | Spindle                                                                          | 1 |
| 8  | 1410/0003Z | Washer (3/8" Small)<br>< Supersession                                            | 1 |
| 9  | 1340/0602Z | Nut<br>Supersession >                                                            | 1 |
| 10 | 1411/0007Z | Washer 5/8<br>Supersession >                                                     | 1 |
| 11 | G18/2      | Key<br>< Supersession                                                            | 1 |
| 12 | 123/01390  | Shaft steering column<br>< Supersession                                          | 1 |
| 13 | 831/00074  | Washer Grooved                                                                   | 1 |
| 14 | 826/00793  | Pin tension<br>Supersession >                                                    | 2 |
| 15 | 192/16400  | Column Steering<br>Supersession >                                                | 1 |
| 16 | :917/02000 | Bearing                                                                          | 2 |
| 17 | 1410/0009Z | Washer<br>< Supersession                                                         | 1 |
| 18 | 1420/0012Z | Washer M20<br>< Supersession                                                     | 1 |
| 19 | 1305/0206Z | Setscrew (3/8" UNF x1")<br>< Supersession                                        | 2 |

|    |                |                                                          |   |
|----|----------------|----------------------------------------------------------|---|
| 20 | 1340/0203Z     | Lock Nut 3/8" UNF<br>< Supersession                      | 2 |
| 21 | :45/905400     | Coupling<br>Supersession >                               | 1 |
| 21 | 45/905400      | Coupling<br>Supersession >                               | 1 |
| 21 | :821/00190     | Clip 'E'<br>< Supersession                               | 1 |
| 21 | ⊘ Not for sale | Multi Supersession<br><M                                 | 1 |
| 22 | 826/00653      | Bolt                                                     | 1 |
| 23 | 823/00232      | Washer                                                   | 1 |
| 24 | 1340/0103Z     | Nut 5/16" UNF<br>< Supersession                          | 1 |
| 25 | 255/35203      | Mount Resilient<br>< Supersession                        | 4 |
| 26 | ⊘ Not for sale | 'See Remark'<br>Steering unit see frame E3-10-1          | 1 |
| 27 | 1315/0409Z     | Setscrew M10 x 35<br>< Supersession                      | 4 |
| 28 | 123/00161      | Plate Retainer                                           | 1 |
| 29 | 823/00408      | Washer 2mm                                               | 4 |
| 30 | 821/00173      | Clip E<br><M<br>Use with 45/901000 item 21               | 1 |
| 30 | 821/00190      | Clip 'E'<br>< Supersession<br>Use with 45/905400 item 21 | 1 |
| 31 | 823/00326      | Washer M10 X 30mm                                        | 1 |