




1	⊘ Not for sale	Wheel steering <M411132 Supersession >	1
1	125/35000	Wheel Steering Supersession >	1
2	114/24903	Clip	4
3	116/00408	Cover <M411132	1
3A	123/03842	Knob Assembly Steering Wheel >M411133 Supersession >	1
3	123/03845	Cap Supersession >	1
4	123/00492	Cap <M411132	1
5	1340/0103Z	Nut 5/16" UNF <M411132 < Supersession	1
6	123/00491	Knob <M411132	1
7	1420/0007Z	Washer (M8) <M411132 Supersession >	1
8	150/32303	Spindle <M411132	1
9	1410/0003Z	Washer (3/8" Small) <M411132 < Supersession	1
10	1340/0602Z	Nut Supersession >	1
11	1411/0007Z	Washer 5/8 Supersession >	1
12	G18/2	Key < Supersession	1
13	2102/0417	Pin Tension	1

14	116/00783	Shaft steering column	1
15	823/00408	Washer 2mm	1
16	2102/0417	Pin Tension	1
17	126/34500	Column steering outer > No Longer Available	1
18	:917/02000	Bearing	2
19	1411/0009Z	Washer Medium 7/8"	1
20	831/00074	Washer Grooved	1
21	1315/0407Z	Setscrew M10 x 25 mm < Supersession	2
23	45/906300	Coupling flexible	1
24	1315/0310Z	Setscrew M8x40 G8.8 < Supersession	2
25	1420/0007Z	Washer (M8) Supersession >	2
26	1370/0203Z	Nut Lock, M8 < Supersession	2
27	255/35203	Mount Resilient < Supersession	4
28	⊘ Not for sale	Valve steering Supersession > For steer valve components, see frame E3-10-1 35/410900 found in supersession chain	1
29	1315/3409Z	Bolt M10 x 35 < Supersession	4
30	123/00161	Plate Retainer	1
31	821/00190	Clip 'E' < Supersession	1
32	823/00326	Washer M10 X 30mm	1
33	123/02828	Shaft extension	1