



A	⊘ Not for sale	NSP	1
1D	704/50030	Diode Washer bottle and shutdown motor.	1
1D	716/10700	Plug single diode 2 way Washer bottle and shutdown motor.	1
1A	721/10121	Harness link horn Only used with JLR0251.	1
1	⊘ Not for sale	Harness Main 130/180T <12-3-01 AMS intro JS130 std > No Longer Available	1
1C	721/10413	Harness link water and oil sensor Only used with JLR0251 or JLR0265.	2
1C	721/10414	Harness link oil overheat switch Only used with JLR0251 or JLR0265.	1
1C	721/10415	Harness link pressure switch Only used with JLR0251 or JLR0265.	4
1	⊘ Not for sale	Harness main <M0890821 Supersession > AMS JS130 std	1
1	721/11391	Harness main, JS130 <M Supersession >	1
1	721/11497	Harness main, JS130 < Supersession	1
1	JLR0231	Harness main <M0758382 < Supersession	1
1	⊘ Not for sale	Harness <M0758684 Supersession >	1
1	⊘ Not for sale	Harness main <M0758798 Supersession >	1
1A	JLR0266	Harness link fuse box Only used with JLR0251.	1

1	JLR0268	Harness main <M0759560	1
1	⊘ Not for sale	Harness main <M0758281 Supersession >	1
1A	JNR0066	Harness link work light Only used with JLR0251.	1
1C	JNR0067	Harness link travel switch also fuel sensor Only used with JLR0251 or JLR0265.	1
2	701/80446	Switch Pressure 12 Bar Upper servo < Supersession	1
2A	JNJ0635	Adapter Use with 701/80446 pressure switch	1
2	KHR1493	Switch pressure 12bar Upper servo <M0758797 Supersession > Lever pressure.	1
3	701/80444	Switch pressure 5 bar Slew < Supersession	2
3	KHR1012	Switch pressure 5bar <M0758797 Supersession > Swing.	2
4	716/30111	Sensor Temperature <7-4-02	2
4	716/30129	Sensor Temperature M16 >8-4-02 Hyd Oil Sensor	2
4	JHR0181	Sender temperature, water/hydraulic oil <12-3-01	2
4	KHR1017	Sender temperature water/hydraulic oil <M0758797 Fitted to item 5 on E1-1-1	2
5	JRR0023	Harness alternator	1
6	JRR0042	Harness beacon < Supersession	1
7	701/80277	Switch temperature <7-4-02	1

7	701/80328	Switch Overheat Warning >8-4-02	1
7	JHR0182	Switch thermo <12-3-01	1
7	KHR1960	Switch thermo <M0758797	1
8	KHR1589	Fuse 25 AMP	2
9	KHR1592	Fuse 65 AMP	1
10	KHR1587	Cover fuse	1
11	KHR1588	Clip	1
12	716/30205	Relay battery < Supersession	1
13	1316/0307Z	Screw Set < Supersession	2
14	1425/0007Z	Washer Spring M8 < Supersession	7
15	1420/0007Z	Washer (M8) Supersession >	7
16	KNR0557	Bracket	1
17	1316/0507Z	Screw M12 x 25mm < Supersession	2
18	1425/0009Z	Washer Spring M12 Supersession >	3
19	1420/0009Z	Washer Plain M12 < Supersession	3
20	KNR0438	Cover	1
21	1316/0303Z	Setscrew M8 x 16mm < Supersession	3
22	718/20026	Cable battery positive to battery relay >M0759015	1
22	⊘ Not for sale	Cable battery lead clamp and cover <M0759014 > No Longer Available	1

22	⊘ Not for sale	Cable battery <M0758557 > No Longer Available	1
23	718/20025	Cable battery negative >M0759015	1
23	⊘ Not for sale	Cable battery lead clamp and cover <M0759014 > No Longer Available	1
23	⊘ Not for sale	Cable battery <M0758557 > No Longer Available	1
24	6063/0007Z	Washer starlock	1
25	JHR0162	Cable Battery Lead Clamp And Cover >M0758558 < Supersession Battery to battery cable	1
25	⊘ Not for sale	Cable battery lead <M0758557 Supersession >	1
26	JNR0055	Cable battery relay to starter motor >M0758558 < Supersession	1
26	⊘ Not for sale	Cable battery <M0758557 Supersession >	1
27	1316/0505Z	Screw M12x20 < Supersession	1
28	6063/0009Z	Washer starlock < Supersession	1
29	KHR1451	Cable Earth	1
30	KHR2119	Screw M6 x 10 < Supersession	2
31	⊘ Not for sale	'See Remark' Engine earth strap, see C2	1
32	826/01347	Tie Cable 160mm For welded stud push fit	56
33	6063/0006Z	Washer starlock	3
34	KHR1957	Clip	4

35	1316/0301Z	Screw < Supersession	1
36	KHR1326	Clamp SPL 18mm dia.	3
36	KHR1327	Clamp 22mm dia. 22mm dia.	1
36	KHR1407	Clamp 25mm 25mm dia.	2
36	KHR1408	Clamp 30mm dia. 30mm dia.	1
36	KHR1444	Clamp 12mm dia. 12mm dia.	3
36	KHR1445	Clamp 15mm dia. 15mm dia.	1
37	KHR2118	Cover fuse	2
42	KHR0737	Screw Pan Head < Supersession	22
43	826/01143	Cable Tie 300mm < Supersession	14
44	KHR0319	Clamp special	8
45	6012/0298Z	Screw pan head	8
46	JHR0128	Bolt Flanged Hex M6X20 < Supersession	3
47	KAR0152	Grommet	2
50	721/10453	Harness Boom Working Lights >M0759561 AMS intro	1
50	JHR0138	Harness <M0758684	1
50	JHR0178	Harness boom working lights <M0759560	1
50	KHR1452	Harness <M0758224	1
51	717/20152	Horn 24 volt Supersession >	1

51	JLR0104	Horn <M0758684 < Supersession	1
51	⊘ Not for sale	Horn low tone <M0758224 Supersession >	1
52	JLR0103	Horn < Supersession	1
53	1316/0305Z	Setscrew M8 x 20 - G10.9 < Supersession	2
54	1425/0007Z	Washer Spring M8 < Supersession	2
55	701/80445	Switch Pressure 20bar Travel < Supersession	1
55	KHR1568	Switch pressure 20bar Travel <M0758797 Supersession > Tracking pressure.	1
56	826/01144	Cable Tie 200mm < Supersession	8
57	1406/0015	Washer Bonded 3/8" < Supersession	1
58	1316/0305Z	Setscrew M8 x 20 - G10.9 < Supersession	1
59	KHR1716	Cap Terminal	2
60	⊘ Not for sale	'See Remark'	1