


L8-2-1 TURBOCHARGER LJ BUILD



1	02/101820	Turbocharger < Supersession	1
2	⊗ Not for sale	Housing assembly Centre	1
3	⊗ Not for sale	Nut lock > No Longer Available	1
4	⊗ Not for sale	Wheel Supersession >	1
5	::02/101260	Ring piston	1
6	::02/101261	Shaft & wheel assembly	1
7	⊗ Not for sale	Shield	1
8	⊗ Not for sale	Bolt	4
9	⊗ Not for sale	Plate back assembly > No Longer Available	1
10	⊗ Not for sale	None serviced part < Supersession	1
11	⊗ Not for sale	Bearing thrust > No Longer Available	1
12	::02/101265	Seal	1
13	::02/101266	Ring piston	1
14	⊗ Not for sale	Collar thrust	1
15	::02/101268	Retainer	4
16	⊗ Not for sale	Bearing Supersession >	2
17	⊗ Not for sale	Housing centre	1
18	:02/101270	Bolt	6
19	:02/101278	Clamp	3
20	:02/101870	Housing compressor < Supersession	1

<https://servicepro.jcb.com/parts?filters=%7B%22activePage%22%3A%22f630cc13-a814-42d5-8dd1-bd9228516846%22%2C%22Specifications.CatalogNum%22%3A...>