




A	⊘ Not for sale	Installation loader control Easycontrol	1
1	128/12637	Knob assembly, 2-switch < Supersession See D1-7-1 for breakdown	1
1	128/14911	Knob assembly,3-switch See D1-7-6 for breakdown	1
2	817/17771	Decal loader lever With Float, Reset	1
2	817/19765	Decal loader control PC	1
5	335/11153	Lever loader, PCH	1
6	116/00416	Joint universal < Supersession	1
7	335/05064	Bracket loader lever mount	1
8	1370/0203Z	Nut Lock, M8 < Supersession	3
9B	:123/08002	Joint ball M8 RH > No Longer Available	1
9D	:826/01108	Lock Nut M8 LH	1
9E	:913/02601	Clevis L/H	1
9	913/10218	Rod control, 404mm	1
9C	:1370/0202Z	Nut Thin (M8) < Supersession	1
10E	:123/08001	Joint ball end M8 left hand thread < Supersession	1
10B	:123/08002	Joint ball M8 RH > No Longer Available	1
10D	:826/01108	Lock Nut M8 LH	1
10	913/10217	Rod control, 387mm	1
10C	:1370/0202Z	Nut Thin (M8) < Supersession	1
11	123/07389	Pin spring, 8mm clevis Supersession >	1

13	1305/0404Z	Setscrew (1/2" UNF x 3/4")	2
14	1417/0014Z	Washer Locking (1/2") Supersession >	4
15	1315/0410Z	Setscrew M10 x 40 < Supersession	2
16	1425/0008Z	Spring Washer M10 Supersession >	2
17	1420/0008Z	Washer Plain M10 Supersession >	2
18	1412/0003Z	Washer (3/8" Large) < Supersession	2
19	826/01249	Nut Rivet M10	2
21	7213/0032	Housing Pin,3 Way Deutsch	1
22	7213/0033	Retainer pin housing 3 way	1