




A	128/11316	Door left hand assembly 更替 >	1
1	⊗ 非卖品	Door left hand side 3CX cab <M903429 > 不再提供	1
1	⊗ 非卖品	Door left hand side 3CX cab > 不再提供	1
2	:331/23358	Seal door 4260mm long < 更替	1
3A	:331/26790	Key cab door 更替 >	1
3	⊗ 非卖品	Handle door left hand < 更替	1
3C	:813/10185	Gasket door handle	1
3B	⊗ 非卖品	None serviced part	1
4	:826/10848	Latch left hand side door > 不再提供	1
5	:827/80143	Glass left hand door tinted 更替 >	1
6	:331/27525	Handle squeeze	1
6A	⊗ 非卖品	Cable release <M903429 更替 >	1
6A	:331/30828	Cable cab door lock	1
7	:331/22479	Cover door lock 3CX cab door 更替 >	1
8	⊗ 非卖品	'See Remark' See Direct glazing	1
9	⊗ 非卖品	'See Remark' Hinge adhesive	1
10	128/13052	Strut gas assembly < 更替	1

11	331/25508	Bracket left hand gas strut 3CX cab 更替 >	1
12	826/01768	Screw M6 x 25 < 更替	2
13	1370/0101Z	Nut (M6) 更替 >	2
14	826/01768	Screw M6 x 25 < 更替 Use with item 7	1
14	826/10887	Screw Button Head Torx M6 x 16 < 更替 Use with item 7	2
15	823/00516	Washer Nylon M6 Use with item 7	3
16	826/10916	Nut lug torque M6 Use with item 7	1
17	1315/0201Z	Setscrew M6 x 12mm < 更替 Use with item 3	2
18	1420/0006Z	Washer Plain M6 更替 > Use with item 3	2
19	826/10887	Screw Button Head Torx M6 x 16 < 更替	3
20	331/27345	Bolt striker <M 更替 >	1
20	:335/04489	Catch door stay 更替 >	1
21	826/00620	Fastener Use with item 20 > 不再提供	1
22	823/10410	Washer M12 Use with item 20	1
22A	826/10947	Nut Plain,M12	1
23	826/10481	Screw Socket M8x40 Use with item 4	2

