




1	02/802633	Alternator Supersession >	1
2	02/802634	Bolt	1
3	02/801076	Nut M10 flange < Supersession	1
4	02/802632	Motor starter	1
4	02/802632R	Motor electrical STARTER MOTOR Reman	1
5	02/802502	Bolt	2
6	02/800784	Lead starter earth	1
7	02/802635	Sensor water temperature	1
8	02/802640	Sensor air pressure	1
9	02/802637	Bracket	1
10	02/802536	Bolt M6x12 Supersession >	1
11	716/30262	Sensor inlet temperature < Supersession	1
12	02/802405	Sensor angle position Camshaft and Crankshaft	1
13	:02/802406	Gasket position sensor crankshaft	1
14	02/802407	Bolt sensor M6x16 < Supersession	1
15	728/80120	Computer engine control 4JJ1X-92kW	1
16	716/30259	Sensor barometric pressure	1
17	716/30262	Sensor inlet temperature < Supersession	1
18	716/30177	Relay safety, pulse < Supersession	1
19	716/30260	Relay thermostart Supersession >	1

20	716/30303	Sensor oil pressure Supersession >	1
21	:32/919404	Washer seal < Supersession	1
22	701/80561	Switch oil level	1