




505-19 > C1-6-1 SENSOR, STEERING



116270

|   |            |                                                                                           |   |
|---|------------|-------------------------------------------------------------------------------------------|---|
| 1 | 701/21300  | Switch proximity<br><M567362<br>1.7m long cable,front axle.                               | 1 |
| 1 | 701/34400  | Switch proximity 750mm long<br>Supersession >                                             | 1 |
| 2 | 701/21400  | Switch proximity<br><M567362<br>3m long cable,rear axle.                                  | 1 |
| 2 | 701/34400  | Switch proximity 750mm long<br>Supersession >                                             | 1 |
| 3 | 157/55600  | Bracket front axle                                                                        | 1 |
| 4 | 157/55800  | Bracket sensor - rear<br><6/3/99<br>< Supersession<br>58'S,67'S,110'S SEE C1-6-4 & C1-6-5 | 1 |
| 4 | 159/11800  | Bracket sensor - rear                                                                     | 1 |
| 5 | 1315/0303Z | Setscrew M8 x 16 G8.8<br>< Supersession                                                   | 2 |
| 6 | 1420/0007Z | Washer (M8)<br>Supersession >                                                             | 2 |
| 7 | 1315/0409Z | Setscrew M10 x 35mm<br>< Supersession<br>505-19(525-58)505-22(525-67)506-36(530-110)      | 2 |
| 7 | 1315/0510Z | Bolt M12x40<br>< Supersession<br>510-40 508-40 (530-120)                                  | 2 |
| 8 | 157/37702  | Stud                                                                                      | 2 |
| 9 | 1370/0202Z | Nut Thin (M8)<br>< Supersession                                                           | 2 |