




1A	701/58829	Actuator Fog Light Switch	1
1	701/60000	Switch Panel Fog light	1
2A	701/58701	Cover 4wd Switch Decal	1
2	701/60000	Switch Panel 2wd switch	1
3A	701/58824	Decal Road Lamps Switch Head/side lights	1
3	701/60004	Switch Panel Head/side lights	1
4A	701/58821	Decal Hazard Switch Hazard warning	1
4	701/60005	Panel 12V 2 Position Hazard warning	1
5A	701/58826	Actuator Switch Front Worklights Front work lights	1
5	701/60004	Switch Panel Front work lights	1
6A	701/58825	Actuator Beacon Switch Lights Beacon light	1
6	701/60000	Switch Panel Beacon light	1
7A	701/58823	Cover HSC switch HSC Switch	1
7	701/60002	Switch Panel HSC Switch	1
8A	701/58842	Cover SRS Switch SoftTouch SRS Switch	1
8	701/60000	Switch Panel SRS Switch	1
9A	701/58835	Cover return to dig switch soft touch Shovel reset	1
9	701/60000	Switch Panel Shovel reset	1

10A	701/58827	Actuator Switch Rear Worklights Rear work lights	1
10	701/60002	Switch Panel Rear work lights	1
11A	701/58828	Actuator wash,wipe switch decal Rear wash/wipe	1
11	701/60003	Switch 12V Rear wash/wipe	1
12A	701/58833	Actuator auxiliary hydraulics Auxiliary hydraulic	1
12	701/60002	Switch Panel Auxiliary hydraulic	1
13	701/60002	Switch Panel Hydraclamp	1
13A	701/80416	Cover Hydraclamp Switch Soft Touch < Supersession	1
14	701/80265	Switch panel blank	1
15	717/08600	Cover Radio Blanking Supersession > For radio see C3-11-1.	1
16	32/925360	Plug Blanking Dome Head 2WS 2WD	1
16	701/42700	Switch 3 postion selector 2WS 4WD	1
17	817/17665	Decal brake mode 3CX cab	1
17	817/18332	Decal brake mode German	1
18	⊘ Not for sale	NSP Plug 2ws/2wd	1