




To: M1050133

A	30/203100	Cooler oil <M808234 High flow machines, elbow one end	1
A	⊘ Not for sale	Cooler hydraulic oil <M806864 Supersession >	1
A	⊘ Not for sale	Cooler Hydraulic Oil >M806865 Supersession >	1
A	30/925399	Cooler hydraulic oil < Supersession	1
A	30/925636	Cooler oil High Flow machines only, elbow one end	1
A	1620/2059	Adaptor STR SAE -12M BSP -12M < Supersession for use with 30/925636, O ring 2401/0508	2
B	⊘ Not for sale	'See Remark' High flow valve	1
1	⊘ Not for sale	'See Remark' Hydrastatic pump	1
1A	816/17065	Adapter 3/4in. x 3/4in.	1
1C	816/17126	Adapter <M808234 O ring 2401/0508	1
1F	⊘ Not for sale	Adapter tee <M808234 > No Longer Available	1
1B	816/60232	Adaptor hose O ring 2401/0510	1
1H	816/90003	Tee Piece 1/4 BSP < Supersession fastens to item 1F	1
1C	816/90055	Adapter 3/4M X 1 1/16 SAE	1
1F	816/90134	Adapter tee 1/4 X 1/4 X 3/4SAE	1

1D	1620/0010	Adapter Includes 'O'Ring <M808234 Supersession > O ring 2401/0508	1
1E	1620/0010	Adapter Includes 'O'Ring <M808234 Supersession > O ring 2401/0508	1
1D	1620/2059	Adaptor STR SAE -12M BSP -12M < Supersession	1
1E	1620/2059	Adaptor STR SAE -12M BSP -12M < Supersession	1
2	⊘ Not for sale	'See Remark' Loader valve	1
2A	816/15061	Adapter <M808234	1
2A	1620/2056	Adaptor STR SAE -10M BSP -10M < Supersession	1
3	⊘ Not for sale	'See Remark' Excavator valve	1
3A	816/17057	Adapter <M808234 Supersession >	1
3B	816/17065	Adapter 3/4in. x 3/4in. <M808234	1
3A	816/90007	Adaptor M/M 5/8" x 3/4" < Supersession	1
3B	816/90137	Adapter G3/4 X 3/4 SAE	1
4	⊘ Not for sale	'See Remark' Check valve	1
5	32/909000	Filter Element	1
5A	816/17061	Adapter <M808234 Supersession >	1
5B	1620/0010	Adapter Includes 'O'Ring <M808234 Supersession >	1

5C	1620/0010	Adapter Includes 'O'Ring <M808234 Supersession >	1
5B	1620/2059	Adaptor STR SAE -12M BSP -12M < Supersession	1
5C	1620/2059	Adaptor STR SAE -12M BSP -12M < Supersession	1
5A	1620/2068	Adaptor 1/2BSP x 1-1/16SAE < Supersession	1
6	2201/0008	Clip Jubilee < Supersession 1 only at pump end with hose 834/00857	2
6	2201/0010	Clip jubilee >M752781 < Supersession Tank end of hose 834/00857	1
7	635/33600	Hose low pressure	1
8	611/22200	Hose Supersession >	1
9	816/90039	Adaptor tee, F/M/M < Supersession Only used when item 10 is fitted	1
10	32/925391	Accumulator Supersession > Fitted only with auxiliary circuits	1
11	816/90027	Adaptor 1/2BSPx3/4SAE < Supersession Only used when item 10 is fitted	1
11A	:2401/0506	O Ring	1
19	635/30700	Hose 1420 mm long	2
19A	635/30700	Hose 1420 mm long	1
20	613/07300	Hose 1/2"BSP x 480mm	1
22A	635/32500	Hose 3/4"BSP 1090mm long From adapter 3B on Excavator valve	1
22	635/32700	Hose	2
23	614/25200	Hose 5/8" BSP 595 mm < Supersession	1

24	611/44900	Hose	1
25	615/20800	Hose 890mm < Supersession	1
28	25/221216	Valve check O ring 2401/0508	1
28	25/975400	Valve check, 2 bar <M808234	1
29	1406/0021	Washer Bonded <M808234 < Supersession	1
29	2401/0508	O Ring	1
32	834/00687	Hose suction <M752780 For hydraulic tank with 30mm outlet	1
32	834/00857	Hose suction >M752781 For hydraulic tank with 50mm outlet	1
36	816/00344	Adapter Tee <M808234 Supersession >	1
36	816/90043	Adaptor Tee M/M/F < Supersession 816/00019 is a 1 inch tee 816/90043 in a 3/4 inch tee MPL 6/19/2023 ref: TW 2368330	1