




1



|   |                |                              |   |
|---|----------------|------------------------------|---|
| A | ⊘ Not for sale | Assembly filter & air intake | 1 |
| 1 | 580/12206      | Filter air assembly          | 1 |
| 2 | :32/926073     | Cover assembly               | 1 |
| 3 | ⊘ Not for sale | None serviced part           | 1 |
| 4 | :32/926074     | Valve dump                   | 1 |
| 5 | :32/926071     | Element air filter main      | 1 |
| 6 | :32/926072     | Element air filter safety    | 1 |
| 7 | 701/80458      | Sensor Vacuum - 80Mbar       | 1 |