




1400 > D3-1-5 CONTROLS THROTTLE & STOP



1	⊘ Not for sale	Pedal throttle Supersession >	1
2	831/00064	Bearing 16x20x25 < Supersession	1
3	814/00201	Spring	1
4	821/00190	Clip 'E' < Supersession	1
5	⊘ Not for sale	Pad > No Longer Available	1
6	1340/0402Z	Nut Thin (1/2" UNF) < Supersession	1
7	910/43800	Cable assembly, c/w lever throttle control <M325311 < Supersession	1
7	910/43900	Cable assembly, c/w lever throttle control < Supersession	1
8	⊘ Not for sale	Lever assembly Used only with 910/24800,910/28300,910/28800 > No Longer Available	1
8A	::910/24804	Screw	1
8	910/42501	Lever assembly throttle control < Supersession Used only with 910/43800,910/43900	1
9	:910/24803	Cable throttle control Used only with 910/24800,910/28300,910/28800	1
9	910/43801	Cable throttle control Used only with 910/43801	1
9	910/43901	Cable throttle control Used only with 910/43900	1
10	:2000/0030	Gaiter < Supersession	2
11	⊘ Not for sale	Knob Supersession >	1
12	⊘ Not for sale	Pin tension Supersession >	1

13	1430/0302	Screw No.10 x 1/2" long < Supersession	3
14	814/00193	Spring with nut	1
15	02/100084	Spring throttle return < Supersession Throttle Return	1
16	910/28400	Cable control Stop < Supersession	1
17	⊘ Not for sale	Cable control Stop Supersession >	1
18	02/100083	Spring stop/return < Supersession Stop Return	1
19	121/81500	Bracket	1
20	910/24902	Handle T	1
21	252/11606	Clip Correction was 109/64502	1
22	1360/0202Z	Screw 2 B.A. x 1/2"	1
23	1416/0003	Washer < Supersession	1
24	1358/0201Z	Nut < Supersession	1