




1	20/201800	Pump	1
2	⊘ Not for sale	Gear set > No Longer Available	1
3	⊘ Not for sale	Dowel > No Longer Available	2
4	:20/200128	Circlip > No Longer Available	1
5	1340/0201Z	Nut < Supersession	4
6	:988/00065	Cover < Supersession Valve Seat & Spool Assembly	1
7	:20/201805	Bolt > No Longer Available	4
8	:1416/0006Z	Washer spring < Supersession	4
9	⊘ Not for sale	Plug Supersession >	1
10	⊘ Not for sale	Spring > No Longer Available	1
11	20/202810	Cap < Supersession	1
12	20/202811	Valve < Supersession	1
13	20/202812	Spring < Supersession	1
14	:1406/0010	Seal Dowty < Supersession	1
15	20/202814	Shim 3.03 thick Supersession >	0
15	⊘ Not for sale	Shim 0.17 thick Supersession >	0
16	:20/200308	Cap < Supersession	1

17	⊘ Not for sale	Ring seal Supersession >	2
18	:20/201802	Kit-seal < Supersession	1
19	⊘ Not for sale	Bearing > No Longer Available	2
20	⊘ Not for sale	Flange > No Longer Available	1
21	816/00192	Cap	1
22	2401/0505	O Ring	1
23	816/40015	Adapter 90 Supersession >	1
24	:2401/0507	O Ring	1
25	816/00111	Adapter	1
26	⊘ Not for sale	Gasket Supersession >	1
27	02/101630	Gear < Supersession	1
28	G18/5	Key	1
29	1305/1709	Bolt	1
29	1305/1718	Bolt < Supersession	2
29A	⊘ Not for sale	Nut	3
29B	1416/0006Z	Washer spring < Supersession	3
30	826/00100	Circle	1