


 506-36 [T4F] > E200-1-1 PUMP/MOTOR INSTALLATION ASSEMBLIES MAIN PUMP ASSEMBLY



332-D0149-3

A	⊘ Not for sale	Pump assembly, Main	1
10	20/925588	Pump Main Hydrailic 3 Stage < Supersession <i>The small gear pump mounted on the end is not available separately. 813/00453 is the o-ring between the pump and the gearbox.</i>	1
20	833/00051	Flange adapter	1
30	2401/0218	O Ring < Supersession	1
40	1305/1908Z	Bolt 1/2" UNC x 1 1/4" < Supersession	4
50	1416/0008Z	Washer Spring (1/2") < Supersession	4
60	813/00453	O Ring Seal < Supersession	1
70	45/916900	Coupling Drive < Supersession	1
80	45/908000	Plug Test Point SAE <i>892/00706 is the mate. Or 892/01234 adaptor w/ hose</i>	1
90	1620/2053	Adaptor 3/8BSPx3/4SAE < Supersession	1
100	1620/2056	Adaptor STR SAE -10M BSP -10M < Supersession	2
110	823/00309	Washer < Supersession	4
120	826/10972	Screw Cap Screw, M12 X 35 TUFLOK	2
130	1316/0509Z	Setscrew M12 x 35mm	2
140	1620/2050	Adaptor G1/4A x 7/16 SAE < Supersession	1
150	4101/0251	Sealant Threadlock 50ml < Supersession	0

