




1400 > L3-4-22 FILTER, AIR LH & LJ BUILDS



082172

1A	32/207600	Filter assembly >M324192 Supersession >	1
1	32/208700	Filter assembly, air <M324191 Supersession >	1
1	333/C3435	Filter air assembly Supersession >	1
2	⊘ Not for sale	None serviced part < Supersession Body	1
3	:32/202602	Element air, primary < Supersession	1
3	:333/C3449	Filter main element	1
4	:32/202601	Element air-safety < Supersession	1
5	:32/203706	Nut with gasket < Supersession	2
6	:32/203704	Valve dust > No Longer Available	1
7	:32/204403	Cover < Supersession	1
8	122/63702	Band Mounting > No Longer Available	1
10	:1410/0001	Washer Supersession >	1
11	1305/0004Z	Bolt	4
12	1340/0003Z	Nut Supersession >	4
13	122/71300	Hose <M319999 Supersession >	1
13	122/94000	Hose Induction Assembly > No Longer Available	1

14	2201/0016	Clip Wormdrive 91-114mm < Supersession	1
15	2201/0013	Clip wormdrive 59/83mm Supersession >	1
16	32/207800	Cap Stack > No Longer Available	1
16A	2201/0015	Clip Worm Drive 80-100mm >M329500 < Supersession Used with cap 32/207800	1
17	813/00327	Seal	1
18	333/C3436	Switch vacuum	1
18	701/09100	Switch Vacuum <M324191 Supersession >	1
18	701/15700	Switch vacuum sensor Supersession >	1
19	816/35003	Adapter <M324191 Also not required with 32/208700	1
20	706/35200	Harness Link air cleaner	1
21	32/207400	Filter pre-cleaner < Supersession Option to item 16	1
22	:32/206303	Bowl	1
23	:32/206301	Cover With wing nut Supersession >	1