


 1400 > H1-1-1 STEERING COLUMN



1	⛔ Not for sale	Wheel steering Supersession >
2	116/00408	Cover
3	123/00492	Cap
4	1340/0103Z	Nut 5/16" UNF < Supersession
5	123/00491	Knob
6	1420/0007Z	Washer (M8) Supersession >
7	150/32303	Spindle
8	1410/0003Z	Washer (3/8" Small) < Supersession
9	1340/0602Z	Nut Supersession >
10	1411/0007Z	Washer 5/8 Supersession >
11	G18/2	Key < Supersession
12	123/01390	Shaft steering column < Supersession
13	831/00074	Washer Grooved
14	826/00793	Pin tension Supersession >
15	192/16400	Column Steering Supersession >
16	:917/02000	Bearing
17	1410/0009Z	Washer < Supersession
18	1420/0012Z	Washer M20 < Supersession

[https://servicepro.icb.com/products/793991813529601633/parts?filters=%7B\"activePage\"%3A\"866a699d-c5c2-43e9-9366-375b3ec337ae\"%2C\"...](https://servicepro.icb.com/products/793991813529601633/parts?filters=%7B\)

