


2025/10/20 14:39:11

 530-70 [T0] > D3-1-1 STEERING COLUMN

1C	123/03842	Knob Assembly Steering Wheel Supersession >	1
1B	123/03845	Cap Supersession >	1
1D	123/03847	Plug blanking	1
1A	125/35000	Wheel Steering Supersession >	1
1G	1340/0602Z	Nut Supersession >	1
1F	1411/0007Z	Washer 5/8 Supersession >	1
1E	G18/2	Key < Supersession	1
2	2102/0422	Pin tension	2
3	1331/0408Z	Bolt Paint Clearing	2
4	160/00959	Column Inner Steer	1
5	831/00074	Washer Grooved	1
6	1315/3408Z	Bolt M10 x 30mm >SN1015045 < Supersession	4
6	1315/3409Z	Bolt M10 x 35 <SN1015045 < Supersession	4
7	162/03203	Lever clamp <i>Nut for the lever clamp is only part of the steering column</i>	1
8	:161/00261	Bracket Steering Mount	1
9	913/00040	Pin Clevis	2
10	126/00310	Column tilt steering outer	1
12	1420/0012Z	Washer M20 < Supersession	1

<https://servicepro.icb.com/products/793991813529601865/parts?filters=%7B%22activePage%22%3A%22c115d883-0b79-4c22-8b33-f10de01ff830%22%2C%22se...>