




H06530

1	⊘ Not for sale	Ram assembly Dozer	0
2	:232/51101	Bush	0
3	⊘ Not for sale	Cylinder	0
4	⊘ Not for sale	Rod piston	0
5	⊘ Not for sale	Bearing gland	0
6	⊘ Not for sale	Head piston	0
7	:233/22454	Dowel	0
8	:1450/0001	Nipple Grease Straight 1/8" < Supersession	0
9	:233/22455	Kit-seal	0
10	⊘ Not for sale	None serviced part < Supersession	0
11	⊘ Not for sale	None serviced part < Supersession	0
12	⊘ Not for sale	None serviced part < Supersession	0
13	⊘ Not for sale	None serviced part < Supersession	0
14	⊘ Not for sale	None serviced part < Supersession	0
15	⊘ Not for sale	None serviced part < Supersession	0
16	⊘ Not for sale	None serviced part < Supersession	0
17	⊘ Not for sale	None serviced part < Supersession	0
18	231/20003	Plate protection < Supersession	0
19	1315/0405Z	Setscrew M10 x 20 mm < Supersession M10 x 20	0

20	823/00416Z	Washer spring < Supersession M10	0
21	2401/0606	O Ring	0