


B2-2-1 SEATBASE CANOPY SINGLE SPEED MACHINES



A	⊘ Not for sale	Seatbase assembly	1
1	236/60429	Seat Seatbase assy canopy Supersession >	1
2	⊘ Not for sale	Electrics Main Assembly	1
3	332/S1223	Cable throttle control assembly	1
4	⊘ Not for sale	Pod left side assembly	1
5	⊘ Not for sale	Control Joystick Right Assembly	1
6	331/42186	Pod Arm Rest	1
7	331/42187	Plug arm rest	1
8	⊘ Not for sale	Panel control assembly	1
9	821/10324	Ring Clamping	1
10	332/S5157	Cover Heater Canopy	1
12	826/10401	Screw Button Head M6 x 35 FOR HEATER BLANK	3
14	1315/0312D	Setscrew M8 x 50 < Supersession FOR POD ARM REST	2
15	1420/0007D	Washer M8 < Supersession FOR POD ARM REST	2
16	331/23575	Knob Controls black Supersession >	1
17	826/01429	Bolt M5 x 16 mm FOR THROTTLE LEVER	4
18	⊘ Not for sale	Lever dozer assembly	1
20	701/80265	Switch panel blank	4
21	701/58826	Actuator Switch Front Worklights	1
22	701/60002	Switch Panel	1
23	826/10996	Screw Button Head M4 x 10mm	4

24	 Not for sale	Seatbase Assembly, Soundproofing	1
25	926/04800	Strip Edging < Supersession PROTECT EARTH LEAD	1
28	1370/0103D	Nut Lock M6 < Supersession	6
29	1420/0006D	Washer Plain M6 < Supersession	6
30	826/01768	Screw M6 x 25 < Supersession	3