




799240

A	345/00390	IA PUMP 110 L/Min IA PUMP 110 L/Min FLOWSHARE	1
1	20/925588	Pump Main Hydrailic 3 Stage < Supersession <i>The small gear pump mounted on the end is not available separately. 813/00453 is the o-ring between the pump and the gearbox.</i> E2-1-3	1
2	833/00051	Flange adapter	1
3	2401/0218	O Ring < Supersession	1
4	1305/1908Z	Bolt 1/2" UNC x 1 1/4" < Supersession	4
5	1416/0008Z	Washer Spring (1/2") < Supersession	4
7	335/10509	Pipe WA Delivery Flowshare (LSP) twin ports	1
8	45/904100	Connector Pressure Test	1
9	1620/2053	Adaptor 3/8BSPx3/4SAE < Supersession	1
10	1620/2056	Adaptor STR SAE -10M BSP -10M < Supersession	2
11	813/00453	O Ring Seal < Supersession	1
12	45/916900	Coupling Drive < Supersession	1
13	826/01702	Setscrew M12 x 35	2
14	823/00309	Washer < Supersession	4
15	614/25200	Hose 5/8" BSP 595 mm < Supersession	1
16	826/01676	Screw Cap 3/8" UNF	4
17	1425/0008Z	Spring Washer M10 Supersession >	4
18	2401/0205	O Ring < Supersession	1

19	1620/2050	Adaptor G1/4A x 7/16 SAE < Supersession	1
20	45/908000	Plug Test Point SAE <i>892/00706 is the mate. Or 892/01234 adaptor w/ hose</i>	1