



1	35/410700	Valve steer 200, painted black with anti-shock	1
1	35/410800	Valve steer 200 load sens without anti-shock <i>Its superseded to 35/410700</i> > No Longer Available	1
2A	:35/408801	Valve dual shock > No Longer Available	2
2	⊘ Not for sale	None serviced part < Supersession	1
3	:35/404202	Kit-repair Supersession >	1
3A	:35/404902	Bearing complete < Supersession	1
7	:35/400502	Ring > No Longer Available	1
8	:35/400507	Pin cross < Supersession	1
9	:35/400508	Ball < Supersession	1
10	:35/400510	Bush > No Longer Available	1
11	⊘ Not for sale	Drive	1
12	⊘ Not for sale	'See Remark' Not fitted or required.	1
13	:35/409301	Plate distributor	1
14	⊘ Not for sale	Kit-gear	1
15	:35/400511	Plate end < Supersession	1
16	⊘ Not for sale	None serviced part Part or item 17	1
17	:35/408903	Screw with bore Supersession >	1
18	⊘ Not for sale	Screw	6

19	:35/407009	Spring kit < Supersession	1
20	:35/408802	Ball	2
21	:35/408803	Pin	2
22A	:35/409303	Valve relief assembly < Supersession	1
23	1620/0004	Adaptor G3/8A-3/4UNF(M) Supersession > Port R & P	2
24	816/17056	Adapter extended Supersession > Port L & T	2
25	2401/0506	O Ring Component part of item 23, 24	1
26	816/13357	Adapter Elbow Supersession > Port load sensed	1
27	2401/0506	O Ring	1