




A	⊘ Not for sale	Assembly lift end	1
1	⊘ Not for sale	Assembly Common Parts Boom	1
2	⊘ Not for sale	Assembly Link & Lever	1
3	⊘ Not for sale	Pad Wear Pad Components	1
4	⊘ Not for sale	Hydraulics Boom Lift End	1
5	⊘ Not for sale	Pivot Pin Assembly <02/03/2014	1
5	⊘ Not for sale	Pivot Pin Assembly >03/03/2014	1
6	⊘ Not for sale	Boom Inner Assembly INCLUDES EXTN LABELS	1
7	333/C5630	Boom Outer Machined 531 >03/03/2014 < Supersession	1
7	335/06656	Boom Outer 530 <02/03/2014 Supersession >	1
8	565/60079	Ram Lift Assembly <18/09/2012 < Supersession	1
8	565/60148	Ram Lift Assembly >19/09/2012	1
9	⊘ Not for sale	Assembly Guard Trash	1
10	563/60126	Ram Tilt 120 x 60 < Supersession 563/60164 may be required for the tilt ram on WASTE or AG applications as 563/60164 has bracket for boom nose cover	1
11	563/60104	Ram Displacement 120 x 60 < Supersession	1
13	25/207300	Cartridge Counter Balance (Seal Kit 332/G9527) 350Bar Does not come with the ram TORQUE TO 85Nm	1

