




1	728/80099	Computer engine control 4HK1X-128kW	1
2	721/12348	Harness engine Supersession >	1
3	721/12347	Harness engine Supersession >	1
4	714/40472	Motor starter Supersession > 714/40521 found in supersession chain	1
5	714/40471	Alternator Supersession >	1
6	716/30312	Sensor camshaft angle	1
7	716/30301	Sensor crankshaft angle	1
8	717/20347	Thermostart Supersession >	1
9	716/30262	Sensor inlet temperature < Supersession	2
10	716/30309	Sensor boost	1
11	02/802211	Thermostat	1
12	02/802212	Thermostat	1
13	716/30305	Sensor water temperature Supersession >	1
14	701/54400	Switch temperature sender M16	1
15	716/30071	Sensor low water level	1
16	JNH0070	Adaptor Vacuum Sensor	1
17	716/30260	Relay thermostart Supersession >	1
18	716/30177	Relay safety, pulse < Supersession	1
19	716/30259	Sensor barometric pressure	1
20	716/30341	Sensor oil pressure < Supersession	1

