




414921

1	714/40089	Motor starter	1
2	714/40090	Alternator 12v-50amp	1
3	716/30153	Solenoid engine stop	1
4	716/30118	Relay starter safety Supersession >	1
5	717/20107	Thermostart glow plug	1
6	8941537231	Connector	1
7	716/18700	Relay heater <M883582 < Supersession	1
8	02/800784	Lead starter earth	1
9	701/60040	Switch oil pressure < Supersession	1
10	701/57300	Switch temperature sender 3/8"	1
11	JHR0181	Sender temperature, water/hydraulic oil	1
12	⊘ Not for sale	Non Serviceable	1
13	9829513250	Cap insulating 8.9x5.3	4
14	⊘ Not for sale	Cap insulator ID=3.8	2
15	9829513330	Cap battery cable 16x13.5	3
16	716/30180	Relay potentiometer Supersession > 716/30179 found in supersession chain	1
17	928/60027	Valve Solenoid Proportional	1
18	716/30119	Relay glow plug timer <M883582	1
18A	716/30158	Relay glow plug timer >M883583	1
19	701/80289	Switch thermo sensor	1
20	721/11078	Harness adapter glow plug timer	1

