




[520-2](#) > L6-3-8 CONTROLS THROTTLE & STOP LD & LJ BUILDS



|     |                |                                                          |
|-----|----------------|----------------------------------------------------------|
| 1   | 153/61200      | Pedal throttle                                           |
| 1   | ⊘ Not for sale | Pedal Accelerator<br>T.U.V Only<br>> No Longer Available |
| 2   | 910/23100      | Cable assembly Throttle                                  |
| 3   | ⊘ Not for sale | None serviced part                                       |
| 4   | :2101/0002     | Pin Clevis                                               |
| 5   | :2103/0305     | Pin Split 1/16 x 1/2<br>< Supersession                   |
| 6   | 1340/0002Z     | Nut<br>< Supersession                                    |
| 7   | 1340/0102Z     | Nut<br>< Supersession                                    |
| 8   | 1420/0007Z     | Washer (M8)<br>Supersession >                            |
| 9   | 831/00064      | Bearing 16x20x25<br>< Supersession                       |
| 10  | 821/00190      | Clip 'E'<br>< Supersession                               |
| 11  | 814/00201      | Spring                                                   |
| 12A | :910/24902     | Handle T                                                 |
| 12  | 910/30400      | Cable assembly Engine stop<br>< Supersession             |
| 13  | 814/00193      | Spring with nut                                          |
| 14  | ⊘ Not for sale | Bracket<br><M501469<br>520<br>> No Longer Available      |
| 14  | ⊘ Not for sale | Bracket<br><M560217<br>520M<br>> No Longer Available     |
| 14  | 153/66100      | Bracket throttle reaction<br>520/520M                    |

