


2025/12/24 15:11:33

1115 > T6-1-2 PUMP, FUEL INJECTION YH BUILD



1A	:17/111901	Motor thermal waxtat	1
1B	:17/111902	O Ring	1
1	17/113900	Pump fuel injection < Supersession	1
2	:17/105201	Solenoid E.S.O.S Supersession >	1
3	::17/110701	Ring seal Supersession >	1
4	::17/105301	Spring	1
5	:17/109503	Connector fuel	1
6	:17/108705	Ring seal Supersession >	1
7	:17/105207	Filter injection pump Supersession >	1
8	:17/110702	Connector fuel leak-off	1
9	:17/108708	Washer	2
10	:17/110703	Valve non-return	1
11	:17/108720	Ring sealing	1
12	:17/108721	Bracket	1
13	Ⓢ Not for sale	Screw > No Longer Available	1
14	:17/108701	Connector fuel pressure	1
14A	17/114101	Washer seal	1
15	:17/110704	Plate support	1
16	:17/105210	Nut Union < Supersession	1
17	:17/108706	Lever fuel shut-off	1

18	:17/105221	Spring > No Longer Available	1
19	:17/105222	Washer cup	1
20	:17/105219	Screw < Supersession	1
21	:17/105220	Washer locking	1
22	:17/108707	Washer	1
23	:17/108712	Lever throttle > No Longer Available	1
24	:17/105222	Washer cup	1
25	:17/108715	Nut lock	1
26	:17/108714	Washer Supersession >	1
27	:17/110904	Guide spring	1
28	:17/110903	Spring return lever	1
29	:17/108710	Bush	1
30	:17/108709	Bush flanged	1
31	:17/109505	Screw	1
32	:17/105228	Nut	1
33	:17/108718	Washer spring	1
34	:02/201712	O Ring	1
35	:02/290037	Gear injection pump < Supersession	1
36	⊗ Not for sale	'See Remark' Part not fitted or required	1
37	02/291016	Screw	4
38	02/291236	Stud	3
39	02/291058	Nut flanged M8 < Supersession	3

40	02/201563	Bracket support < Supersession	1
41	826/00901	Screw < Supersession	1
42	826/00869	Screw flange head	1