



A	128/11643	Installation actuator sideshift	1
1	128/11642	Kingpost	1
1A	:831/10277	Bearing liner	2
2	331/26833	Carriage kingpost Supersession >	1
2A	831/10283	Bearing liner	2
3	811/90298	Pin pivot	1
4	831/10277	Bearing liner	2
5	1391/3425Z	Screw cap	1
6	1370/0302Z	Nut Thin M10 < Supersession	4
7	1450/0001	Nipple Grease Straight 1/8" < Supersession	9
8	835/00017	Cap Grease Nipple Supersession >	9
9	811/90299	Pin pivot 155 x 50mm dia.	1
10	831/00114	Washer thrust	2
11	1391/3422Z	Capscrew	1
12	331/26830	Plate trunnion plate	1
13	831/10278	Bearing liner	2
14	⊘ Not for sale	Plate cover If Fitted	1
14A	⊘ Not for sale	Pad wear Fitted with Hammer circuit-secure with 15A	1
15	1315/0305Z	Setscrew M8 x 20 G8.8 < Supersession See 15A if Hammer circuit is fitted	8
15A	1315/0307Z	Setscrew M8x25 G8.8 < Supersession Use with 14A only	2

16	1420/0007Z	Washer (M8) Supersession >	8
17	1316/3818	Bolt	4
18	1370/0701Z	Nut (M20) < Supersession	4
19	823/00604	Washer hardened M20 Supersession >	8
20	831/10280	Bearing thrust	4
21	811/90300	Pin pivot	2
22	1315/3422Z	Bolt M10 x 120	2
23	1370/0302Z	Nut Thin M10 < Supersession	7
24	811/90301	Pin pivot	1
25	1391/3420Z	Capscrew Supersession >	2
26	811/90302	Pin pivot	1
28	⊘ Not for sale	Clamp hose WA	2
29	⊘ Not for sale	Clamp Standard m/c fitment	4
29	331/31283	Clamp Clamp hammer return hose	1
29	331/31302	Clamp Clamp hammer feed hose	1
30	1315/0407Z	Setscrew M10 x 25 mm < Supersession	2
31	1420/0008Z	Washer Plain M10 Supersession >	2
32	331/29501	Plate lower cover	2
33	1370/0203Z	Nut Lock, M8	4