


2025/11/21 13:15:53

N2-1-1 CYLINDER HEAD AA & AB BUILD



1A	⊘ Not for sale	Head cylinder assembly Supersession > Double valve spring	1
1	⊘ Not for sale	None serviced part Head assembly, Single valve spring	1
2	⊘ Not for sale	None serviced part Head	1
3	:02/100396	Plug core D=32mm < Supersession	1
4	:02/200047	Plug core D=16mm	4
5	:02/200050	Valve inlet	4
6	:02/101883	Guide inlet valve > No Longer Available	4
7	:02/100638	Seat spring < Supersession	8
8A	:02/101968	Spring Valve outer Supersession > Used only with item 1A	8
8B	:02/101969	Spring Valve inner Supersession > Used only with item 1A	8
8	:02/200052	Spring Valve Used only with item 1	8
9	:02/100668	Seal valve < Supersession	8
10A	:02/101970	Holder Collet Used only with item 1A	8
10	:02/200053	Holder Collet Used only with item 1	8
11	:02/100024	Collet Supersession >	8
12	:02/101705	Valve exhaust, standard < Supersession	4

13	:02/101884	Guide exhaust valve > No Longer Available	4
14	⊘ Not for sale	Plate Cover Supersession >	1
15	:02/101785	Gasket < Supersession	1
16	:02/291016	Screw	1
17	:826/00869	Screw Flange Head	1
18	:02/100095	Plug taper < Supersession	2
19	:02/100409	Plug taper threaded < Supersession	4
20	02/100122	Bolt cylinder head < Supersession	2
21	02/100120	Bolt cylinder head check engine for quantities either 10 or 12 bolts < Supersession	8
22	02/100121	Bolt cylinder head < Supersession	12
23	⊘ Not for sale	Gasket cylinder head Supersession >	1
24	701/37400	Switch temperature	1
25	823/00264	Washer Aluminium (I/D=16mm) < Supersession	1