




A	128/12632	GA BATTERY ISOLATOR	1
1	332/F3103	Battery Wet Charge 12V 110AH >M1708294 Supersession >	1
1	729/10655	Battery wet charge 130Ah <M1708293 < Supersession	1
1	729/20655	Battery dry charge 130Ah Supersession >	1
2	⊘ Not for sale	'See Remark' Fuel tank/battery box See index B1	1
3	718/20118	Lead battery negative	1
4	718/20276	Lead battery,positive	1
4A	998/10911	Terminal battery lug < Supersession	1
4B	998/10912	Bolt battery lug M6	1
5	⊘ Not for sale	Bolt swing 175mm long <M1349622 Supersession >	1
5	826/01798	Bolt M6 x 200mm >M1349623 < Supersession	1
6	128/17397	Bolt swing link mounting >M1349623	1
6	826/10774	Bolt swing clamp link mounting <M1349622	1
7	331/35543	Clamp Battery <M1708293	1
7	332/G3398	Clamp battery >M1708294	1
8	1411/0001Z	Washer (1/4" Medium) < Supersession	2
9	826/01115	Nut Wing M6	2

10	708/10040	Cover battery terminal,red For battery positive terminal	1
11	716/30077	Box Fuselink <i>Loadalls - The two maxi fuses are 716/16400 (Part of the Panel Harness) Connectors: 7232/0008 - Blue 7232/0009 - Grey</i>	1
12	716/15900	Fuse 40Amp	1
13	716/30081	Fuse Maxi 50Amp	2
14	716/16400	Fuse 60Amp < Supersession	1
15	817/17068	Label fuselink box < Supersession	1
16	821/00487	Clamp 3 Pipe	1
17	821/00488	Plate Clamp	1
18	1315/3214Z	Bolt M6 x 60	2
19	2410/0205	Grommet Hole Diameter 12.7mm	3
20	826/01144	Cable Tie 200mm < Supersession	4
21	123/06759	Clip	1
22	718/20120	Lead fuse link 375 mm	1
23	701/47400	Switch Isolator >M1708869 <i>701/47401 is the key</i>	1
23	701/80552	Switch isolator <M1708868	1
24	:701/47401	Key isolator switch (to 701/47400) >M1708869	1
24	:701/80553	Key isolator switch <M1708868	1
25	331/30658	Plate battery isolator	1
26	265/00893	Cover Battery Isolator Supersession >	1
27	1391/3307Z	Capscrew M8 x 25mm < Supersession	2
28	1370/0203Z	Nut Lock, M8 < Supersession	2

29	1315/0308Z	Setscrew M8 x 30	3
30	718/20140	Lead battery, negative	1
31	826/01144	Cable Tie 200mm ↳ Suppression	4