




A	331/49852	Tank hydraulic,assembly	1
1	⊘ Not for sale	None serviced part Use item 0A	1
2	⊘ Not for sale	'See Remark' See E3-7-1	1
3	⊘ Not for sale	Plate access,hydraulic <M1042141 Supersession >	1
3	:331/45050	Plate filter	1
3A	::826/01828	Nut rivet Supersession >	2
4	:701/80325	Switch temperature	1
5	:242/00178	Gasket <M1042551	1
6	:123/00295	Breather	1
7	:265/01289	Gauge Sight	1
8	:32/904200	Strainer Suction 1 1/2BSP Thread, 63AF Hexagon	1
9	:816/80012	Plug Magnetic 3/4"BSP <Apr 2005 < Supersession Fitted to early machines only	1
10	:1420/0007D	Washer M8 < Supersession	11
11	:1315/0310D	Setscrew M8 x 40 mm <M1042141 < Supersession	2
12	:1315/0309D	Setscrew M8 x 35 mm < Supersession	2
13	:1315/0308D	Setscrew M8 x 30 G8.8 < Supersession	6
14	:826/01828	Nut rivet Supersession >	8
15	826/01554	Screw Socket Screw M8 x 25	6

16	1420/0007D	Washer M8 < Supersession	6
17	816/90217	Adaptor	1
18	:1370/0203D	Nut Lock M8 >M1042142 < Supersession	2
19	:331/43049	Bracket bonnet latch Refer to Bonnet page for latch details	1