






JS130 R3 [T0] > E4-1-4 RAM, BOOM FOR USE WITH HOSE BURST PROTECTION



A	⊘ Not for sale	Ram assembly right hand boom > No Longer Available	1
A	JNV0120	Ram assembly left hand boom > No Longer Available	1
1	⊘ Not for sale	'See Remark' Cylinder	1
2	⊘ Not for sale	Bush > No Longer Available	1
3	:LAU0087	Seal wiper > No Longer Available	2
4	:JHP0037	Nipple Grease Supersession >	3
5	⊘ Not for sale	Rod piston > No Longer Available	1
6	::6900/0702	Bush < Supersession	1
7	:KHV0249	Ring wiper Supersession >	2
8	⊘ Not for sale	Kit-cap end > No Longer Available	1
9	⊘ Not for sale	Bush	1
10	::LMU0140	Ring snap	1
11	:LAU0178	Ring wiper < Supersession	1
12	:LBQ1101	O Ring > No Longer Available	1
13	⊘ Not for sale	Washer lock > No Longer Available	1
14	:LBU0041	Ring back-up	1
15	:LAU0101	Ring u	1
16	:LAU0106	Seal gland	1
17	⊘ Not for sale	Ring back-up	1

18	⊘ Not for sale	O Ring	1
19	⊘ Not for sale	Ring back-up > No Longer Available	2
20	:LBQ0952	O Ring	1
21	⊘ Not for sale	Bearing cushion	1
22	⊘ Not for sale	Piston	1
23	⊘ Not for sale	Ring slide > No Longer Available	2
24	⊘ Not for sale	None serviced part < Supersession See item 29	1
25	⊘ Not for sale	Shim	1
26	⊘ Not for sale	Nut > No Longer Available	1
27	:LPU0073	Ball steel	1
28	:LUU0099	Screw	1
29	LQU0080	Kit repair < Supersession	1
30	⊘ Not for sale	Pipe boom ram right hand > No Longer Available	1
30	JNV0108	Pipe boom ram left hand > No Longer Available	1
31	JNV0098	Valve hose burst check boom ram > No Longer Available	1
32	:6900/0002	Kit-seal hose burst valve > No Longer Available	1
33	⊘ Not for sale	'See Remark' O Ring	1
34	⊘ Not for sale	'See Remark' O Ring	1
35	1391/3420	Screw cap M10 x 100 < Supersession	4
36	1391/3409	Capscrew M10 x 35	4
37	⊘ Not for sale	Bracket > No Longer Available	2

38	1315/0303Z	Setscrew M8 x 16 G8.8 < Supersession	4
39	1315/0307Z	Setscrew M8x25 G8.8 < Supersession	4
40	1420/0007Z	Washer (M8) Supersession >	8
41	1370/0203Z	Nut Lock, M8 < Supersession	4