




210 [T0] > G1-2-1 BRAKE, AXLE



130281

1	⊘ Not for sale	Piston brake > No Longer Available	2
2	813/50025	Seal brake piston (square section)	2
3	813/50026	Seal Brake Piston (square section) < Supersession	2
4	440/00708	Plate pressure < Supersession	2
5	440/00707	Plate counter brake NLA. use 440/00720 with 440/00721 in axle set > No Longer Available	8
5	458/20286	Plate brake counter	8
6	440/00706	Plate friction brake NLA use 440/00721 with 440/00720 in axle sets > No Longer Available	6
6	458/20281	Plate brake friction	6
7	828/00208	O Ring	2
8	821/00290	Circlip internal	2
9	⊘ Not for sale	'See Remark' Adaptor, brake pipe	2
10	⊘ Not for sale	'See Remark' Seal	4
11	816/60040	Screw Bleed < Supersession	2
12	835/00017	Cap Grease Nipple Supersession >	2
13	⊘ Not for sale	'See Remark' Piston housing see Index F	1
14	826/01343	Screw Grub, Nylon Coated	2