




872070

1	02/802037	Cover cylinder head Supersession >	1
2	⊘ Not for sale	None serviced part	1
3	:02/802169	Connector air breather	1
4	:02/801872	Gasket air breather	1
5	:02/802125	Bolt < Supersession	2
6	:02/801179	Cap engine oil filler	1
7	::02/801178	Seal oil filler cap	1
8	:02/801175	Plate oil baffle	1
9	:02/802042	Screw	6
10	:02/802039	Gasket rocker cover	1
11	:02/802038	Mounting Mounting rubber	11
12-2	02/801602	Bolt L=55 < Supersession	7
12-1	02/802394	Bolt cyl. head < Supersession	2
13	834/11236	Hose	1
14	2201/0007	Clip Wormdrive < Supersession	2
15	821/10467	Clamp	1
16-1	829/31364	Spacer	1
16	1316/0308D	Setscrew M8x30 G10.9	1
17	1420/0007D	Washer M8 < Supersession	1
19	02/802061	Cover lower cylinder	1
20	02/802056	Gasket	1
21	02/802550	Bolt < Supersession	2

22	02/802483	Bolt < Supersession	3
23	02/801986	Connector	1
24	02/802043	Nut M8 < Supersession	2
25	02/801988	Gasket	2