




A	⊘ Not for sale	Installation loader control Easycontrol	1
1	128/H0545	Knob assembly 3 switches	1
2	817/19765	Decal loader control PC	1
5	335/11153	Lever loader, PCH	1
6	116/00416	Joint universal < Supersession	1
7	128/F9823	Bracket loader lever mount	1
9A	:331/20202	Joint ball joint M8 < Supersession	1
9C	:826/01108	Lock Nut M8 LH	1
9D	:913/02301	Clevis fork end	1
9	913/10218	Rod control, 404mm	1
9B	:1370/0202Z	Nut Thin (M8) < Supersession	1
10D	:123/08001	Joint ball end M8 left hand thread < Supersession	1
10A	:331/20202	Joint ball joint M8 < Supersession	1
10C	:826/01108	Lock Nut M8 LH	1
10	913/10217	Rod control, 387mm	1
10B	:1370/0202Z	Nut Thin (M8) < Supersession	1
11	123/07389	Pin spring, 8mm clevis Supersession >	1
13	1305/0404Z	Setscrew (1/2" UNF x 3/4")	2
14	1417/0014Z	Washer Locking (1/2") Supersession >	4
15	1315/0410Z	Setscrew M10 x 40 < Supersession	2

17	1420/0008Z	Washer Plain M10 Supersession >	2
18	1412/0003Z	Washer (3/8" Large) < Supersession	2
19	826/01249	Nut Rivet M10	2
21	7213/0032	Housing Pin,3 Way Deutsch	1
22	7213/0033	Retainer pin housing 3 way	1