




1A	:02/802585	Sensor fuel temp.	1
1	17/930500	Pump fuel injection assembly 更替 >	1
1B	:17/930501	Kit fuel pump overhaul	1
2	:02/801924	Key	1
3	:02/802203	Nut	1
4	02/802307	O Ring < 更替	1
5	02/802288	Case assembly bearing inj.pump	1
6	02/802193	Gasket	1
7	02/802287	Gear injection pump	1
8	02/802707	Valve feed pump < 更替	1
9	32/919404	Washer seal < 更替	3
10	02/802690	Pipe < 更替	1
11	332/E9515	Pipe fuel < 更替	1
12	02/802484	Bolt < 更替	3
13	02/802128	Bolt < 更替	1
14	02/802154	Nut	2
15	02/802671	Bolt < 更替	1
16	02/801816	Stud water pump	1
17	02/802135	Bolt	1

