

A	⊘ Not for sale	Pipe LP Fuel	1
1	320/07052	Pipe Fuel Filter To Fuel Injection Pump < Supersession	1
2	320/07059	Pipe Fuel Lift Pump To Fuel Filter < Supersession	1
3	320/07192	Pipe Assembly LP Leakoff Pipe	1
4	320/07055	Clip Pipe < Supersession	3
5	320/07033	Ring snap Supersession >	4