




128-G0710-2

A	⛔ Not for sale	Installation fixed cathead Piling Master
1	334/E9260	Cathead fixed
2	334/G0932	Guide rope
3	1315/3320Z	Bolt (M8 x 100)
4	1420/0007Z	Washer (M8) Supersession >
5	1370/0203Z	Nut Lock, M8 < Supersession
6	334/F7473	Pulley cathead
7	826/01493	Screw Countersunk M6x25
8	334/F2161	Wheel tooth, target
9	716/M4433	Sensor gear tooth
10	1420/0006Z	Washer Plain M6 Supersession >
11	1315/0205Z	Setscrew M6x20 Supersession >
12	811/50571	Pin pivot
13	1450/0001	Nipple Grease Straight 1/8" < Supersession
14	1315/3520Z	Bolt M12 x 100mm < Supersession
15	1370/0403Z	Nut Lock, M12 < Supersession
16	334/G0788	Spacer pulley
18	334/G1057	Stop lower
19	701/H4036	Sensor stabiliser leg drop down
20	1391/9402D	Capscrew M4 x 12mm < Supersession
21	400/E5952	Bracket mounting, sensor

22	1315/3311Z	Bolt (M8 X 45) < Supersession
23	826/01106	Nut Rivet M8 < Supersession
24	332/Y1231	Shim pulley
25	400/E1467	Spacer 10mm thick
26	4103/3500	Loctite 424 Supersession >

Following JCB's Serviceability Review, only those items with part numbers are available to purchase for this Component. For any other items please purchase the next available parent assembly.