




1	10/300709	Cover	2
2	:904/20262	Seal o ring	2
3	:450/24415	Stop shaft	2
4	:450/24423	Bolt M8 x 25	8
5	:10/300710	Casing hub outer	1
6	:10/300711	Pin > No Longer Available	6
7	:10/906479	Plug Magnetic M22 x 1.5 Supersession >	2
8	:826/01450	Nut wheel Supersession >	38
9	:10/300712	Plate thrust 3mm	6
10	:10/300713	Bearing	6
11	:10/300714	Spacer	6
12	:10/300715	Gear pinion	6
13	:10/300716	Plate thrust	6
14	:10/300717	Gear side	2
15	:10/300718	Circlip	2
16	:10/300719	Disk brake drum	2
17	:10/300376	Disk brake	10
18	:10/300378	Plate pressure, 4.25mm <i>Please refer to the service manual to identify pressure plate and quantity required.</i>	8
18	:10/301378	Plate pressure 5.0mm <i>Please refer to the service manual to identify pressure plate and quantity required.</i>	8
19	:10/300720	Pin 112mm x 8mm > No Longer Available	12
20	:10/300721	Ring retaining	2
21	:10/301379	Plate pressure > No Longer Available	2

22	:10/908908	Spring	2
23	:10/908909	Retainer	2
24	:450/24414	Plate locking	2
25	:10/300725	Nut adjusting > No Longer Available	2
26	:10/300726	Circlip	2
27	:10/300727	Plate trust	2
28	:10/300658	Bearing	2
29	:10/300728	Gear support	2
30	:10/300729	Gear anulus	2
31	:10/300730	Casing hub inner	2
32	:450/24431	Stud wheel < Supersession	38
33	:904/20263	Seal	2
34	:10/300731	Piston > No Longer Available	2
35	:904/20264	Seal	2
36	:10/908876	Bearing	2
37	:904/20265	Seal	2
38	:10/300672	Spindle right side > No Longer Available	1
39	:10/906509	Breather oil	2
40	:450/24417	Screw hex hd.	12
41	:10/908887	Seal O ring	2
42	:10/300673	Spindle left side > No Longer Available	1
43	:10/908889	Screw	32
44	:10/300732	Ring	2
45	:10/906514	Cover oil breather cowl	2
46	:10/300370	Washer	2

