




|    |                |                                                         |   |
|----|----------------|---------------------------------------------------------|---|
| A  | 290/01167      | Bracket relay<br>If fitted<br>> No Longer Available     | 1 |
| 3  | 701/45500      | Switch ignition<br>Supersession >                       | 1 |
| 3A | :701/45501     | Key Door/Ignition<br>< Supersession                     | 1 |
| 3B | 701/45502      | Cap Splash<br>< Supersession                            | 1 |
| 4  | 701/39700      | Switch rocker<br><M TBA                                 | 1 |
| 4  | 701/39800      | Switch panel                                            | 1 |
| 5  | 701/46900      | Switch<br><See Note<br>9 pin connector indicator switch | 2 |
| 5  | 701/53500      | Switch<br>>See Note<br>5 pin connector indicator switch | 1 |
| 6B | ⊘ Not for sale | Insert wash/wipe<br>Supersession >                      | 1 |
| 6  | 701/39300      | Switch                                                  | 2 |
| 6A | 701/40100      | Switch                                                  | 1 |
| 7  | 701/40400      | Switch                                                  | 1 |
| 8  | ⊘ Not for sale | Decal hazard warning<br>Supersession >                  | 1 |
| 9  | 701/09800      | Switch blank<br>Supersession >                          | 4 |
| 10 | 701/40500      | Switch                                                  | 1 |
| 11 | 700/15800      | Holder warning light                                    | 4 |
| 12 | 701/16504      | Insert alternator warning                               | 1 |
| 13 | 701/40100      | Switch                                                  | 1 |
| 14 | 701/16506      | Insert engine oil pressure warning                      | 1 |
|    |                |                                                         |   |

|    |                |                                                       |   |
|----|----------------|-------------------------------------------------------|---|
| 15 | 701/00019      | Insert trans.oil pressure                             | 1 |
| 16 | 701/16505      | Insert water temp warning                             | 1 |
| 17 | 701/00021      | Insert oil temperature transmission                   | 1 |
| 18 | 701/16503      | Insert air filter blocked warning                     | 1 |
| 19 | 701/00060      | Insert park brake                                     | 1 |
| 20 | 701/00064      | Insert auxiliary hydraulics                           | 1 |
| 21 | 701/00008      | Insert symbol                                         | 1 |
| 22 | 701/10500      | Insert                                                | 1 |
| 23 | 701/39300      | Switch                                                | 1 |
| 24 | 716/05706      | Fuse 15 amp<br>< Supersession                         | 1 |
| 25 | 716/05705      | Fuse 10A<br>< Supersession<br>Quantities may vary.    | 5 |
| 26 | 716/05703      | Fuse 5 Amp<br>< Supersession<br>Quantities may vary.  | 2 |
| 27 | 704/50078      | Diode gate, 7 way<br>7 diode pack                     | 1 |
| 27 | 716/12100      | Diode gate<br><M752675<br>5 diode pack                | 1 |
| 28 | 716/10700      | Plug single diode 2 way<br>>M752370                   | 1 |
| 28 | 716/15400      | Plug Diode<br>< Supersession                          | 1 |
| 30 | 716/13300      | Diode Gate Assembly Double                            | 1 |
| 31 | 704/50153      | Hourmeter<br>< Supersession                           | 1 |
| 37 | 716/C6032      | Relay Hazard Flasher Unit 12V 6x21W<br>< Supersession | 1 |
| 38 | Ⓢ Not for sale | Relay sequence<br>Supersession >                      | 1 |
| 39 | 716/09800      | Relay 40A Main Power<br>< Supersession                | 1 |

|    |                |                                                                 |   |
|----|----------------|-----------------------------------------------------------------|---|
| 40 | 716/09800      | Relay 40A Main Power<br>< Supersession                          | 1 |
| 41 | 704/10000      | Alarm Buzzer<br>< Supersession                                  | 1 |
| 42 | 332/S3465      | Switch oil pressure Deutsch connector)                          | 1 |
| 42 | 701/41700      | Switch oil pressure M10 yellow body (AMP connector)<br><M808661 | 1 |
| 43 | 701/50200      | Insert indicator<br>< Supersession                              | 1 |
| 44 | 701/39300      | Switch<br>Hand held attachment circuit                          | 1 |
| 45 | ⊘ Not for sale | Decal Hi-Lo-flow<br>Supersession >                              | 1 |
| 46 | 701/39900      | Switch                                                          | 1 |
| 47 | 701/39300      | Switch                                                          | 1 |
| 48 | 701/11002      | Insert<br>< Supersession                                        | 1 |
| 49 | ⊘ Not for sale | Insert wash/wipe<br>Supersession >                              | 1 |
| 50 | 701/00037      | Decal beacon<br>< Supersession                                  | 1 |
| 51 | ⊘ Not for sale | Decal heater fan blower<br>Supersession >                       | 1 |
| 52 | 701/00086      | Insert high flow                                                | 1 |
| 53 | 701/48300      | Switch                                                          | 1 |
| 54 | 701/00087      | Decal hydraulic float                                           | 1 |
| 55 | 716/09800      | Relay 40A Main Power<br>< Supersession<br>High flow             | 3 |
| 56 | ⊘ Not for sale | Relay Micro (Black)<br>Supersession ><br>brake timer            | 1 |